# HOW TO SET UP INTRUSION DETECTION TO TRIGGER SMART TRACKING WHEN PTZ IS DOING PATROL

Note
1. Do not enable smart tracking.
2. Smart tracking has a disadvantage that if the tracking target stops during travelling, PTZ will not mark the target with green square. Without green square PTZ treats it as the ending of the tracking, the PTZ will go back to its original position.

Step 1

Step 2

Step 3

Step 4

Local
System
Network
Video/Audio
Image
PTZ
Event
  Basic Event
  Smart Event
Storage

Audio Exception Detection   Face Detection   **Intrusion Detection**   Line Crossing Detection

☑ Enable

Area Settings ⟩ Arming Schedule ⟩ **Linkage Method**

☐ **Normal Linkage**	☐ **Trigger Alarm Output**	☐ **Trigger Recording**
☐ Send Email	☐ A->1	☐ A1
☑ Notify Surveillance Center	☐ A->2	
☐ Upload to FTP/Memory Card/...		
☑ Smart Tracking		

Step 3
tick on Smart Tracking

Local
System
Network
Video/Audio
Image
PTZ
Event
  Basic Event
  Smart Event
Storage

Audio Exception Detection   Face Detection   **Intrusion Detection**   Line Crossing Detection   Region Entrance Detection

☑ Enable

Area Settings ⟩ Arming Schedule ⟩ Linkage Method

Region [2 ▾]

02-05-2018 Wed 14:16:41

#2#

2001

Lock

1	Preset 1
2	Preset 2
3	Preset 3
4	Preset 4
5	Preset 5
6	Preset 6
7	Preset 7
8	Preset 8

Step 4
just same as step 3
here we set up
region 2, so one
region is for one
preset and one
intrusion detection
rule only.

then call preset 2 to
set up intrusion
detection

[Draw Area] [Clear]

Threshold(s) ———○——— 1
Sensitivity ——○—————— 50

do not forget to enable smart
tracking in linkage action.